

GDS2000使用可能プリンター一覧表

NF Corpration

Apple	EPSON	EPSON	EPSON	HP
Color StyleWriter 4100	PM-880C	Stylus Color 1520	EM-900C	LaserJet4V, 4Si
Color StyleWriter 4500	PM-930C	Stylus Color 3000	EM-930C	LaserJet 5 series
Color StyleWriter 6500	PM-950C	Stylus Photo	MC-2000	LaserJet 5Si
	PM-970C	Stylus Photo 700	MC-5000	LaserJet 6 series
	PM-2000C	Stylus Photo EX	MC-7000	DeskJet 970C
Brother	PM-2200C	Stylus Photo EX3	MC-9000	LaserJet 1022n
HL-1440 series	PM-3000C	Stylus Photo 720	MC-10000	LaserJet 1020
	PM-3300C	Stylus Photo 750	MJ-930C	LaserJet 1015
CANON	PM-3500C	Stylus Photo 780	MJ-5100C	LaserJet 1010
BJC 30	PM-3700C	Stylus Photo 785EPX	MJ-6000C	LaserJet 1300
BJC 50	PM-4000PX	Stylus Photo 790	MJ-8000C	
BJC 55	PM-5000C	Stylus Photo 810	PM-700C	
BJC 80	PM-5000C	Stylus Photo 820		LEXMARK
BJC 85	PM-7000C	Stylus Photo 825		4076
BJC 210	PM-9000C	Stylus Photo 830	HP	Z42
BJC 240	PM-10000	Stylus Photo 870	DeskJet 340	Z43
BJC 250	PM-D750	Stylus Photo 875	DeskJet 400	Z52
BJC 1000	PM-G700	Stylus Photo 875	DeskJet 500	Z53
BJC 2000	PX-V500	Stylus Photo 890	DesignJet 230	
BJC 3000	PX-7000	Stylus Photo 895	DesignJet 250C	
BJC 4300	PX-9000	Stylus Photo 900	DesignJet 700	
BJC 4400 photo	AL-C8600	Stylus Photo 915	DesignJet 750C	
BJC 6000	Stylus C59	Stylus Photo 925	DesignJet 2500C	
BJC 6100	Stylus C60	Stylus Photo 935	DesignJet 3500C	
BJC 6200	Stylus C61	Stylus Photo 950	DesignJet 430	
BJC 6500	Stylus C62	Stylus Photo 960	DesignJet 450C	
BJC 7000	Stylus C63	Stylus Photo 1200	DesignJet 455CA	
BJC 7100	Stylus C64	Stylus Photo 1270	DesignJet 488CA	
BJC 8200	Stylus C65	Stylus Photo 1280	DeskJet 500C	
S200	Stylus C70	Stylus Photo 1290	DeskJet 520	
S400	Stylus C79	Stylus Photo 2000P	DeskJet 540C	
S450	Stylus C80	Stylus Photo 2100	DeskJet 550C	
S800	Stylus C82	Stylus Photo 2200	DeskJet 560C	
S4500	Stylus C83	Stylus Photo R200	DeskJet 600/600C	
	Stylus C84	Stylus Photo R300	DeskJet 600 series	
	Stylus Color	Stylus Photo RX500	DeskJet 690 series	
EPSON	Stylus Color Pro	Stylus Photo RX600	DeskJet 810C	
Stylus C20SX	Stylus Color Pro XL	Stylus Pro 5000	DeskJet 812C	
Stylus C20	Stylus Color 400	Stylus Pro 5500	DeskJet 840C	
Stylus C40SX	Stylus Color 440	Stylus Pro 7000	DeskJet 842C	
Stylus C40UX	Stylus Color 460	Stylus Pro 7500	DeskJet 845C	
Stylus C41SX	Stylus Color 480	Stylus Pro 7600	DeskJet 850C	
Stylus C41UX	Stylus Color 500	Stylus Pro 9000	DeskJet 855C	
Stylus C42SX	Stylus Color 580	Stylus Pro 9500	DeskJet 870C	
Stylus C42UX	Stylus Color 600	Stylus Pro 9600	DeskJet 890C	
Stylus C43SX	Stylus Color 640	Stylus Pro 10000	DeskJet 895C	
Stylus C43UX	Stylus Color 660	Stylus Scan 2000	DeskJet 900 series	
Stylus C44SX	Stylus Color 670	Stylus Scan 2500	DeskJet 1100C	
Stylus C44UX	Stylus Color 680	Stylus CX-3100	DeskJet 1120C	
Stylus C45	Stylus Color 740	Stylus CX-3200	DeskJet 1200C	
Stylus C50	Stylus Color 760	Stylus CX-5100	DeskJet 1220C	
PM-700C	Stylus Color 777	Stylus CX-5200	DeskJet 1600C	
PM-730C	Stylus Color 800	Stylus CX-5300	DeskJet 2000 series	
PM-740C	Stylus Color 850	Stylus CX-5400	DeskJet 2500 series	
PM-750C	Stylus Color 860	Stylus CX-6300	PhotoSmart P1000	
PM-760C	Stylus Color 880	Stylus CX-6400	PhotoSmart P1100	
PM-770C	Stylus Color 880	Stylus CX-8300	LaserJet series	
PM-780C	Stylus Color 83	Stylus CX-8400	LaserJet P series	
PM-790PT	Stylus Color 900	CL-700	LaserJet series	
PM-800C	Stylus Color 980	CL-750	LaserJet 4 series	
PM-850PT	Stylus Color 1160	CL-760	LaserJet 4L	
PM-870C	Stylus Color 1500			